





HCAL Pulse Shape



Simulation of HCAL Electronics


Pulse shape generation & interpretation

- Beam parameters
- Shower in scintillator layers
- Wavelength shifting in fibers
- Transport to photodetector
- Photodetector response
- QIE response
- FADC conversion





Beam Parameters



Size of the luminous region


- Crossing angle and transverse beam size determine size of the luminous region
- So small, 5cm rms, no effect on calorimeter

Duration of each crossing

- Longitudinal beam distribution determines interaction rate versus time
- Gaussian with a mean = 0 (by definition) and $\sigma < 1$ nsec
- No effect on calorimeter



Shower Sampling



Time of flight to first interaction


- B-field is necessary
- Time varies with eta – taken out in hardware
- Time jitter distribution is exponential
- Most showers begin in the crystals

Scintillator samples shower development

- Very fast response, ~2.5 nsec time constant
- Readout has depth segmentation with a different calibration for each compartment
- “Tail-catcher” compartment is not included in the Level 1 trigger sum – available for HLTs



WLS Fiber Readout



Wavelength shifting fibers in every tile


- Length of the fiber varies with eta, ~ 7 nsec
- Time constant of the fluor is ~ 12.5 nsec
- Efficiency of conversion is $\sim 5\%$ so Poisson fluctuations are important for both pulse shape and length at low energies, < 1 GeV

Clear fibers from tiles to photodetectors

- Each layer in depth has a different length of fiber, partially compensated ($\beta = 1/2c$)
- Eta dependence of average length taken out in the hardware (along with time-of-flight)
- Some light is lost here as well



Photodetector Response



Quantum efficiency


- Typically about 12%
- Changes the point where Poisson shape fluctuations are important to $E < 10$ GeV
- Thick compartment: 10 photoelectrons/GeV

Time response

- Determined by the reverse bias voltage
- Different for 19-pixel and 73-pixel devices because of capacitance
- May be fast enough that convolution with the photoelectron distribution isn't needed except at low energies.



Simulation Logic - 1



Pick t-zero

- Gaussian with mean = 0, sigma =

Track particle(s) to first interaction


- B-field on
- Keep track of time

Shower development

- Layer by layer deposition of energy in scintillators
- Keep track of times of deposition layer by layer, Tscint., in 2 nsec bins



Simulation Logic - 2



WLS fiber photon distribution


- Convert E to N photons for each scintillator layer using Poisson statistics
- Draw N(E) photons from the wls fiber filling time distribution (geometry + $\exp(-t/12.5 \text{ nsec})$)
- Use Tscint as the filling function start time
- Propagate photon pulse to the HPD including the mirror on the far end and attenuation
- Look up table of delta-time for each scintillator

Sum over depth segments

- Add up the photon pulses from all layers in the depth compartment in 2 nsec bins



Simulation Logic - 3



Convert to photoelectrons

- For each photon, draw from a Poisson probability for conversion with mean 12%

Convert to photodetector pulse


- Convolute photoelectron pulse with the impulse response function of the HPD

Convert to QIE analog pulse

- Convolute HPD pulse with the impulse response of the QIE - which is amplitude dependent



Simulation Logic - 4



Integrate into time slices


- Using the time offset (+ or -) determined at the point where the photoelectron distribution was created, integrate the pulse in 25 nsec intervals.
- The nominal time offset has the pulse starting 5 nsec into the first 25 nsec interval to allow for early fluctuations

FADC the integrated values

- Use a look up table for the FADC floating point transfer function – range and mantissa



Simulation Logic - 5



Linearize the FADC results

- Use a lookup table giving 16-bit integers

Generate trigger primitives


- Add layer 0 to the main compartment
- Use a sliding 5 time-sample window to extract the energy, weights: -1.5, -1.5, 1.0, 1.0, 1.0
- Use a lookup table to transform the TPG results according to the Level 1 compression algorithm de jour

Generate HLT data

- Issue is improved energy estimate for zero suppression



Note re Forward Calor.



Sampling is based on Cerenkov light generated in quartz fibers


Photodetector is a photomultiplier tube

Intrinsically fast

- At the PMT, pulse is ~10 nsec at the base
- Simulation of cable and QIE analog section shows pulse is over within one 25 nsec clock interval
- No pile up from prior beam crossings
- Only have the intrinsic pile up from multiple hits in a tower from the same beam crossing




Previous Experimental Data on Photodetectors by HF Group




R6427

350 GeV Pion Signal





Now vs. Later



Test beam measurements later


- Planned for summer of 2002

Interim possibility now - simplify

- Based on estimates that show fluctuations in time and area due to shower development and time jitter are far smaller than the resolution – 100% at 1 GeV, 30% at 10 GeV:
- Add all of the scintillator light in a given compartment, ignore timing details
- Use a universal pulse shape
- Use photostatistics of the HPD



Summary



Energy is the sum of three consecutive time samples

- E = total charge in the pulse (minus baseline)

Low energies will be a problem for:


- Identifying the correct crossing (shape fluct.)
- Pile up at high luminosity

Pulse shape is only an estimate

- Open issue re possible neutron induced tail
- Layer to HPD time-of-arrival distribution put in crudely as a rectangular smearing



Priorities to ORCA



1. Digitizations

- HF

- Fast - crossings are independent

- HB and HE

- Replace pulse shape FADC sampling with pulse integration FADC values


2. Photostatistics

- HF, HB and HE

- Depth compartments - need pe/GeV numbers
- Draw $N(E)$ photoelectrons from a Poisson



Priorities to ORCA




3. Pedestal and noise

- Pedestal is an electronic offset from $FADC = 0$
- Marks the position of zero energy
 - $E = E(FADC) - E(Pedestal)$
- Noise is 4000 electrons sigma
 - Equivalent to 2 photoelectrons HB, HE, HO
 - Equivalent to 0.1 photoelectrons HF
- FADC bin size is 6000 electrons
 - Equivalent to 3 photoelectrons HB, HE, HO
 - Equivalent to 0.15 photoelectrons HF



Studies



Trigger primitive generator algorithm

- Energy extraction options
- Bunch crossing identification options
- Remember the latency constraint

Zero suppression algorithm

- Energy extraction options
- Bunch crossing already known
- “Sharp” threshold desired

Phase of the beam clock

- Relative timing between cal pulse & beam
- Optimum may depend on luminosity