FERMILAB  ENGINEERING NOTE	SECTION PPD/ETT	PROJECT CDF - CLC		SERIAL - CAT	AGORY	PAGE 1
SUBJECT			NAME Mayling Wong			
Pressure Accumulation in PMT due to Helium Permeation			DATE  2 April :	2002	REVISION DATE	

## **Summary:**

The bulbs of the photomultiplier (PMT) tubes of the CDF-Cherenkov Luminosity Counter have a fused quartz window. The PMTs are manufactured with a  $10^4$  Pa vacuum pressure. This note shows that the pressure in the PMT will become reach 0.02-0.03 Pa due to helium permeation through the quartz window if the PMT is exposed to air for one year. The PMT pressure will reach 0.04 Pa in one year if the PMT is exposed to a pressurized environment at 8 psig (1.5 atm) that contains 5 ppm of helium.

### Given:

The construction materials of the PMT are borosilicate glass for its sides and quartz for its window. The quartz window with dimensions 2.54 cm diameter and 1 mm thickness is the vacuum barrier for a PMT. The PMT is constructed so that it has a vacuum pressure of  $10^4$  Pa [1]. The permeation rate of helium through quartz is  $1 \times 10^{-10}$  cc-mm/sec/cm<sup>2</sup>/cm-Hg at 25°C [2]. (The definition of permeability is the mass flow of a gas in cubic centimeters per second per area in cm<sup>2</sup> through a thickness in mm which has a pressure difference in cm-Hg) The partial pressure of helium gas in air is 0.5 Pa, or  $3.75 \times 10^{-4}$  cm-Hg (5.2 ppm) [3]. The permeation rate for borosilicate glass is  $1 \times 10^{-12}$  cc-mm/sec/cm<sup>2</sup>/cm-Hg [4].

### Find:

The total pressure accumulation in the PMT of helium due to permeation if the PMT is exposed to:

- 1. Air at atmospheric pressure,
- 2. Isobutane at 8psig (1.5 atm) that contains 5 ppm of helium.

### Solution:

The total amount of helium permeating through the quartz window is the sum of the helium permeating in short periods of time.

# Assumptions:

- The permeation rate of helium through borosilicate glass is significantly smaller than the permeation rate through quartz. Thus, the accumulation of helium in the PMT through the quartz window will be considered.
- The permeation rate remains constant during a time interval.
- The pressure difference across the quartz window remains constant during a time interval.
- The PMT remains in room temperature  $T = 25^{\circ}C = 298.15^{\circ}K$ .

The area of the quartz window is 5.07 cm<sup>2</sup>.

The total volume inside the PMT is calculated from its dimensions D = 25.4 mm, L = 68.0 mm. If the bulb is completely empty, the volume under vacuum is 34.4 cc.

#### **Initial conditions:**

- Partial pressure of helium in atmosphere (outside the PMT quartz window) =  $0.5 \text{ Pa} = 3.75 \times 10^4 \text{ cm-Hg}$
- Pressure inside the PMT =  $1 \times 10^{-4}$  Pa =  $7.5 \times 10^{-8}$  cm-Hg
- The entire volume inside the bulb is empty.

## First time interval:

- Time period  $dt_1 = 300$  seconds
- Pressure difference  $dp_1 = 3.75 \times 10^4 7.5 \times 10^8 \text{ cm-Hg} = 3.75 \times 10^4 \text{ cm-Hg}$
- Amount of helium that permeated through the quartz window during this time period:

$$V_{1} = \frac{10^{-10} \frac{\text{cc} - \text{mm}}{\text{sec} - \text{cm}^{2} - \text{cm} - \text{Hg}} *300 \text{ sec}*5.07 \text{ cm}^{2} *3.75 \text{x} 10^{-4} \text{ cm} - \text{Hg}}{1 \text{ mm}}$$

$$V_{1} = 5.7 \text{x} 10^{-11} \text{cc}$$

• Converting the amount of helium from volume to moles:

$$n_1 = \frac{5.7 \times 10^{-11} \text{ cc}}{1000 \frac{\text{cc}}{\text{L}} * 22.4 \frac{\text{L}}{\text{mol}}}$$
$$n_1 = 2.5 \times 10^{-15} \text{ mol}$$

• Assuming that helium is an ideal gas, the additional pressure in the PMT as a result of the incoming helium is calculated using the ideal gas law p=n\*R\*T/V:

$$p_{1} = \frac{2.5 \times 10^{-15} \, \text{mol} * 83.14 \frac{\text{mbar} - L}{\text{mol} - K} * 298.15 \,^{\circ} \, \text{K}}{\frac{34.4 \, \text{cc}}{1000 \,^{\circ} \text{cc}/L}}$$

$$p_{1} = 1.8 \times 10^{-9} \, \text{mbar}$$

$$p_{1} = 1.8 \times 10^{-7} \, \text{Pa}$$


The calculations are repeated for additional time intervals. This method of modeling is used to determine pressure accumulation for the PMT volume that is 100% empty space, 75% empty space, and 50% empty space. The model is also compared to the pressure data listed in the manufacturer's handbook [1]. The following assumptions were made about the handbook's data:

• The Hamamatsu PMT that was modeled was 931A.


- The entire bulb of the PMT is made of quartz.
- The bulb thickness is 2 mm.
- The empty bulb volume is 32 cc.
- The bulb surface area through which the helium permeates is 51.1 cm<sup>2</sup>.


Figure 1 shows the helium accumulation inside the PMT over time.

Figure 1 - Pressure Accumulation in PMT due to Helium Permeation CLC PMT - Hamamatsu R5800Q; Function of Volume of Empty Space inside PMT



As seen in Figure 1, if the CLC's PMT is left exposed to air at atmospheric pressure for one year, the pressure inside the PMT becomes 0.02-0.03 Pa, depending on the amount of empty space there is inside the bulb. It would take about 31 years for the pressure inside of the PMT to equal the partial pressure of helium in atmosphere. Figure 2 shows the pressure accumulation inside the PMT if it is exposed to pressurized isobutene at 8 psig (1.5 atm) that contains 5 ppm of helium.





After one year of exposure to the higher partial pressure of helium, the pressure inside the PMT would be 0.04 Pa, assuming the bulb of the PMT R5800Q had 75% of empty space.

## References:

- 1. <u>Hamamatsu Photomultiplier Tubes</u> catalog, April, 2000.
- 2. Dr. Larry Zeng, GE Quartz Worldwide, private conversation.
- 3. O'Hanlon, J.F., A User's Guide to Vacuum Technology, 2<sup>nd</sup> edition, John Wiley & Sons, 1989.
- 4. Roth, Vacuum Sealing Techniques, Pergamon Press, 1966.